

TELEPÍTÉS

ProClip

Please read all of the instructions and look at the pictures before attaching the ProClip mount. It is important to install the mount first: any device holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place the mount by the right side of the air vent so the short side of the upper and lower parts are toward the driver's side. Hook the upper edge under the frame surrounding the air vent.



2. Press the lower part of the mount upward and forward so the lower edge hooks/clips over the frame surrounding the air vent.



3. Press on the mount so the edges hook into place and the adhesive tape attaches properly.



4. The ProClip mount is in place.

Az alábbiakkal kompatibilis

Lexus LS Series 18-24 (USA)