

# TELEPÍTÉS

## ProClip

Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder/equipment is to be attached after the mount is in place.



1. Use the enclosed alcohol pad to clean the area where the mount will be installed. Peel off the adhesive tape cover. Place/Press the lower edge of the mount into the gap between the air vent mesh panel and the surrounding frame.



2. Press downward and forward on top of the mount. Hook/Clip the upper edge into the gap between the mesh panel and the surrounding frame.



Press downward and upward on the lower and upper parts on the inside of the mount so the edges go all the way into the gap.



3. This mount can be installed anywhere along the air vent mesh panel.

# **Az alábbiakkal kompatibilis**

Honda HR-V 23-24 (USA)