

# TELEPÍTÉS

## ProClip

Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to install the ProClip mount first: any holder/equipment is to be attached after the mount is in place. This mount consists of two parts.



1. Choose if you prefer to have the device installed on the driver's or passenger's side of the screen, and place the face plate onto the corresponding side of the mount. Make sure the face plate is on the correct side and attach it to the mount base with the included screws (Phillips screwdriver). Place the mount above the screen.



2. Slowly and firmly, press down on both sides of the mount to slide/hook it onto the screen.



3. Press downward until the mount is securely in place.



4. The ProClip mount is in place.

## **Az alábbiakkal kompatibilis**

Volvo EX30 24-24 Volvo EX30 24-25