

TELEPÍTÉS

Tartozékok

Figyelem! Összeszerelés előtt kérjük, figyelmesen olvassa el a használati utasítást és nézze meg az ábrákat, mielőtt rögzíti a ProClip-et!



1. A mellékelt képek alapján lazítsa meg a csavarokat.



2. Helyezze a 215005 talpazatot a kívánt pozícióba, és a mellékelt csavarokkal rögzítse a helyére. Helyezze a záró gyűrűt a 215005 talpazatra. Megjegyzés: Fontos, hogy a mellékelt képeknek megfelelően helyezze a záró gyűrűt a talpazatra.



3. Nyomja az eredeti talpazatot a 215005 talpazatra. Rögzítse az eredeti talpazatot a 215005 talpazatra a rögzítő gyűrűvel. A talpazat a készülékkel a helyére került.



Az alábbiakkal kompatibilis

Becker Active 43 Talk	Becker Active 43 Traffic	Becker Active 43 Transit
Becker Active 50	Becker Ready 43	Becker Ready 43 Talk
Becker Ready 43 Traffic	Becker Ready 50	Becker Traffic Assist Z098
Becker Traffic Assist Z100 Crocodile	Becker Traffic Assist Z101	Becker Traffic Assist Z102
Becker Traffic Assist Z108	Becker Traffic Assist Z112	Becker Traffic Assist Z113
Becker Traffic Assist Z116	Becker Traffic Assist Z201	Becker Traffic Assist Z203
Becker Traffic Assist Z204	Becker Traffic Assist Z205	Becker Traffic Assist Z213
Becker Traffic Assist Z215	Mio Moov 200	Mio Moov 330
Mio Moov 370	Mio Moov 580	Mio Moov M610
Navman F10	Navman MY30	Navman MY500XT
Navman MY50T	Navman MY55T	Navman S30
Navman S50	Navman S70	Navman S90i